



- 1** Cut horizontal 2" x 4" to the distance between posts less 1" (2.5 cm).
- 2** Cut vertical 2" x 4" to desired height.
- 3** Assemble 2" x 4" to Gate Kit brackets with included screws.
- 4** Attach gate hinges to fence post on the desired side with included screws. Attach fence boards to the gate frame.



- 1** Couper les 2" x 4" horizontaux à la distance entre les poteaux moins 1" (2,5 cm).
- 2** Couper les 2" x 4" verticaux à la hauteur désirée.
- 3** Assembler les 2" x 4" aux supports pour barrière à l'aide des vis fournies.
- 4** Visser les charnières au poteau de clôture du côté désiré. Visser les planches sur le cadre de la barrière.