Here is the most up-to-date version of the installation VIDEO



### **INSTALLATION GUIDE**



Here is the most up-to-date version of the installation **GUIDE** 



**SQUARE BALUSTRES** 26" - 32" - 36"

#17226-27-32-33-36-37



#### Got a question? - Contact us:

First contact our friendly customer service team for assistance.

Email: info@pylex.com or phone: 1-800-264-1881


Monday to Friday: 8:30 am to 4:30 pm (EST)


Replacement for damaged or missing parts will be shipped promptly.

Rev.: 52-0529



DECK AND FENCE HARDWARE
WWW.PYLEX.COM / 1 800-264-1881






## **NUMBER OF BALUSTERS REQUIRED**







DISTANCE		
FROM	ТО	BALUSTERS
39-3/4"	35-1/2"	8
35-1/4"	31"	7
30-3/4"	26-1/2"	6
26-1/4"	22"	5
21-3/4"	17-1/2"	4
17-1/4"	13"	3
12-3/4"	8-1/2"	2
8-1/4"	4"	1

#### STEP 1 - INSTALLATION ON THE RAILING




# MEASURE THE DISTANCE BETWEEN POSTS



48<sup>\*\*</sup>

USE TWO 2" X 4" PIECES LONGER THAN THE FINAL MEASUREMENT (50")\*

Ø 1/16"




2" X 4" TOP

USE A SQUARE TO DRAW A LINE ON THE TOP 2" X 4"




PRE-DRILL ALL MARKS ON THE TOP 2" X 4"




**\*USE YOUR MEASUREMENTS** 

#### **STEP 2 - INSTALLATION ON THE RAILING**








#### STEP 3 - INSTALLATION ON THE RAILING







FIX THE LOWER RAILING TO THE POSTS

AND PLACE THE BALUSTERS IN THE CONNECTORS AS ILLUSTRATED.






MAXIMUM DISTANCE BETWEEN BALUSTERS IS 3-7/8" (WE USE 3-3/4")


2 INSTALL THE UPPER RAILING INTO THE ALREADY INSTALLED BALUSTERS

FIX THE RAILING TO THE POSTS

#### **STEP 4 - INSTALLATION ON STAIR HANDRAIL**









PLACE THE LOWER

#### **STEP 6 - INSTALLATION ON STAIR HANDRAIL**







LEAN THE
RAILING AGAINST
THE POSTS
AS ILLUSTRATED


DRAW AND CUT ALONG THE LINE


#### **STEP 7 - INSTALLATION ON STAIR HANDRAIL**



## FIX THE LOWER STAIR RAILING TO THE POSTS 1










#### **STEP 8 - INSTALLATION ON STAIR HANDRAIL**





ADJUST THE RAILING SO THAT THE BALUSTERS ARE STRAIGHT BY MOVING THE RAILING FROM LEFT TO RIGHT.





DRAW A LINE, REMOVE THE RAILING AND CUT ALONG THE LINE





# REINSTALL THE STAIR RAILING INTO THE ALREADY INSTALLED BALUSTERS



# FIX THE RAILING TO THE POSTS

INSTALLATION TYPES
MAY VARY

MAXIMUM DISTANCE BETWEEN BALUSTERS IS 3-1/8" (WE USE 3-3/4")





#### **Satisfied with your Pylex product?**

Please let us know by sharing pictures with us at info@pylex.com You can also write a review online about your purchase.

(By sending your image, you agree to give Pylex the right to it in its marketing activities).



#### YOU LIKED OUR PRODUCT?

Visit our website: www.pylex.com to see all our products or scan this QR code to have access to our catalog!



**Pylex Guarantee Certificate** 



Follow us on: **f o p in** 









